Compund

FN + F1	Display Brightness -
FN + F2	Display Brightness +
FN + F3	Win + Tab
FN + F4	Win + E
FN + F5	Email
FN + F6	Home page

Media Player

FN + F7	Previous Track
FN + F8	Play / Pause
FN + F9	Next Track
FN + F10	Mute
FN + F11	Volume -
FN + F12	Volume +

Lucine

FN + \ |	Switch luci
FN + 1	FPS Default
FN + 2	MOBA/LOL
FN + 3	Ufficio
FN + `~	Registra modalità
FN + <-	Light speed -
FN + ->	Light speed +
FN + ↑	Light brightness +
FN + ↓	Light brightness -
FN + X	Spegni luci
FN + Esc	**Premi** 3 secondi per resettare le luci