Washing Machines Set Up.

Water Level	Soil Level	Tempature	Option
King size load	Regular Soil	Warm/E-nergy Saver Warm	One Rinse
Varies by the amount of clothes you want to wash at the time.	Turn to 'Ultra Soil' if the clothes are covered in dirt.	If the clothes are all sweaty and stinky then put the setting on 'Warm'. If not, 'Energy Saver Warm'. If you are putting towels or any bedding in, turn to hot.	I dont see the point in rinsing the clothes two times...

Setting it up to use.

Washing Machine Set Up Continued.

Cycles

Push Handle in, Turn Handle to 'Normal', Pull the Handle out.

Push in the Handle to 'Pause' the wash.

Setting it up to use.

Before You Put In The Washer.

Check the pockets of the pants , shirts, and shorts.	Tie strings that are on pants and those kinds of things.	Put the clothes in evenly. Spread then around so that they are at the same height when you start the thing.	MAKE SURE THAT THE WASHER IS EMPTY BEFORE YOU START IT!!!!!!

Check list.

Soap Block or Whatever It Is.

Soap	Softner	Color Safe Bleach
Fill the cup with soap, and then dump the cup under the water at the back.	Fill the cup Half way, and then dump it into the hole in the middle of the washer.	Fill the cup Half way, and then dump it into the hole on the Right of the washer.
Rinse out cup a few times.	Rinse out cup a few times.	Rinse out cup a few times.

Soaps and stuff to put in to make your clothes clean.

By **Todd Town** (Zmanwrestler)

cheatography.com/zmanwrestler/

Published 17th June, 2014.
Last updated 13th May, 2016.

Sponsored by **Readable.com**
Measure your website readability!
https://readable.com