RGB Backlit Modes	
Fn (Function) + F10	Cycle through the available display modes:

a	
a	a
a	

RGB Backlit Modes	
Fn + F10	Cycle between the different modes:
Wave (Default)	◆Halo
Color cycle	◆Breathe
Rain drop	◆100% Full backlight
Ripple	◆Radar
Rainbow reactive	Off (No backlight)
◆Reactive	

◆ Allows further color adjustment: