Powering the Console

The PS4 can be turned on by doing one of the following:
- Press the **PS** button on any of the controllers.
- Press the **power** button on the left side of the console where the power indicator light is located.
- Press the **power** button on the VR headset's controls.

Turning Off the Console

There are two ways to power down the console:
- With a DUALSHOCK®4 controller, press and hold the **PS** button, navigate to the **Power** menu, and select **Enter Rest Mode**.
- Press and hold the **Power** button on the left-hand side of the console's front until you hear a beep.