Anduril 2 flashlight Cheat Sheet

by petong via cheatography.com/173778/cs/36511/

From Off Advanced Mode

1C	On (ramp mode, memorized level)
1H	On (ramp mode, floor level)
2C	On (ramp mode, ceiling level)
2H	On (momentary turbo)
3C	Battcheck mode
3H	Strobe mode (whichever was used last)
4C	Lockout mode
5C	Momentary mode
7C	Aux LEDs: Next pattern
7H	Aux LEDs: Next color
9H	Misc config menu (varies per light)
10H	Simple UI Ramp Config Menu
13H	Factory reset (on some lights)
15C	Version check

Simple UI Ramp Config Menu 7H from Off

1	Floor	(default = 20/150)
2	Ceiling	(default = 120/150)
3	Steps	(default = 5)
4	Turbo Style	(default = 0, no turbo)

Battery Check Mode (3C)

1C	Off
2C	Next mode (Temp check, Beacon, SOS)
7H	Voltage Config Menu

Misc Config 9H from Off

1	Tint ramp style	0 = smooth 1 = toggle
2	Jump Start level	1 to 150, usually between 20 and 50

Ramp Mode (On)

1C	On
1H	Ramp (up, with reversing)
2H	Ramp (down)
2C	Go to/from ceiling or turbo
3C	Change ramp style (smooth / stepped)
3H	Tint ramping (on some lights) / Momentary turbo (on lights without tint ramping)
4C	Lockout mode
5C	Momentary mode
5H	Sunset Timer and Add 5 Mins
7H	Ramp config menu (1: floor, 2: ceiling, 3: speed/-steps)
10C	Turn on manual memory and save current brightnes
10H	Ramp Extras config menu

Ramp Config Menu (Smooth) 7H from On

1	Floor	(default = 1/150)
2	Ceiling	(default = 120/150)
3	Ramp Speed	(default = 1, fastest speed)

Ramp Config (Stepped) 7H from On

1	Floor	(default = 20/150)
2	Ceiling	(default = 120/150)
3	# of steps	(default = 7)

Lockout

1C/1H	Momentary moon (lowest floor)
2C/2H	Momentary moon (highest floor, or manual mem level)
3C	Unlock (go to "Off" mode)
4C	On (ramp mode, memorized level)
4H	On (ramp mode, floor level)
5C	On (ramp mode, ceiling level)
7C	Aux LEDs: Next pattern
7H	Aux LEDs: Next color
10H	Auto-lock config menu: 1 click == 1 min

Strobe Mode 3H from Off

1C	Turn Off
2C	Next Mode
1H	Increase Brightness/S-trobe
2H	Decrease Brightness/S-trobe
5C	Momentary Mode

Candle -> Bike -> Party -> Tactical -> Lightning

Aux Colors

7H from Off or Lockout

- Red
- Yellow (Red+Green)
- Green
- Cyan (Green+Blue)
- Blue
- Purple (Blue+Red)
- White (Red+Green+Blue)
- Disco
- Rainbow
- Voltage

Sponsored by **CrosswordCheats.com**
Learn to solve cryptic crosswords!
http://crosswordcheats.com