

### Common Controls

|                              |   |
|------------------------------|---|
| tap                          | tap tempo   |
| alt + tap                    | toggle external clock                                       |
| alt + play (while stopped)   | arm recording   |
| play                         | toggles playback of the deck loop                           |
| alt + play (while playing)   | engages overdubbing   |
| play (while overdubbing)     | disengages overdubbing                                      |
| alt + pitch                  | snaps to: +/- fifth, octave, 2 octaves, zero                |
| reverse                      | moves the playhead in reverse                               |
| alt + reverse                | engages resampling / deck-to-deck recording                 |
| mixer slider A <--> B        | mixes output of decks A and B; center = both simultaneously |
| alt + mix                    | sets the feedback level of the overdub/delay effect         |
| alt + sequence pad           | engages trigger sequencer recording                         |
| alt + sequence pad (hold 2s) | deletes that deck's sequence                                |
| tap (hold) + deck A mix      | adjust metronome level                                      |

### Routing Switch

|                 |  |
|-----------------|--|
| left (mono)     | Two independent mono decks (input and output)  |
| center (stereo) | Inputs hard-panned and routed to both decks. Outputs contain stereo mix of both decks. |
| right (mystery) | TBD  |

### CV

|          |                       |
|----------|-----------------------|
| gate in  | triggers the playhead |
| clock in | 4PPQN clock signal    |
| mixer in | controls mix          |

Note: when **mixer in** is patched, mixer slider becomes Deck A offset envelope  
adjusts shape from no/sharp thru flavors of attack/decay

### Reel Mode

Inspired by 1940s and 1960s tape music. This mode is monophonic, where time and pitch are bound together (like real tape).

recording starts when input signal crosses threshold of -40dB

### Slice Mode

This is a polyphonic looper, where pitch and time are disconnected (time stretching).

recording starts / stops quantized to clock (next quarter note)

alt + size CCW: monophonic - CW: polyphonic

### Drift Mode

Designed for generative and granular textures.

recording starts when input signal crosses threshold of -40dB

position moves playhead: where to generate grains from

size grain distributino: how wide an area around playhead to generate grains from within

alt + envelope envelope length (re-trigger period 40ms..5s?)

alt + size window size / density (grain size 40..500ms?)

### FX: Grit & Flux

fx pad + tap switch fx

Grit (orange, texture-based)

orange: bit crusher

grit fx pad + pitch softer <--> harsher / lower bitrate

grit fx pad + mix fx output gain

yellow: analog saturation

grit fx pad + pitch saturation <--> distortion

grit fx pad + mix fx output gain

Flux (pink, time-based)

pink: tape delay

flux fx pad + pitch change tape delay speed

flux fx pad + mix delay output mix

flux fx pad + position delay feedback



By **Bill Smith** (Naenyn)  
[cheatography.com/naenyn/](https://cheatography.com/naenyn/)

Not published yet.  
Last updated 5th January, 2026.  
Page 1 of 1.

Sponsored by **ApolloPad.com**  
Everyone has a novel in them. Finish Yours!  
<https://apollopad.com>