## Cheatography

## Ducky mecha mini Cheat Sheet by VirtuaLeech via cheatography.com/184678/cs/38560/

Backlighting modes		RGB LED Zone Customization Mod	
Fn+Alt+T	Wave (Default) Color Cycle Rain Drop Ripple Random Reactive Reactive * Halo *	Fn+Alt+G	CM1 cycle: First step: Turn on customized zone at Second step: Turn customized zone at in breathe mode. Third step: Turn off
	Breathe *	Fn+Alt+B	CM2 cycle: See CM
	100% Full Backlit * Radar * Backlit off	Fn+Alt+ CapsLock (REC)	Press for 3 seconds the G (CM1) and B keys light up, choos
Fn+Alt+J Fn+Alt+L	Decrease speed Increase speed		layer for setting, pre again and start reco
Fn+Alt+T	Hold for 3 seconds to turn off all backlit * can be changed Adjust color red (R) brightness.	CapsLock+Z	Adjust color red (R)
		CapsLock+X	Adjust color green
		CapsLock+C	Adjust color blue (E
Fn+Alt+Z Fn+Alt+X	Adjust color green (G)	CapsLock+V	Erase all LED light
Fn+Alt+C Fn+Alt+V	It+C brightness.	CapsLock+ Spacebar	Color palette
Spacebar Erase colo Activate cc various col press on th the keys w	brightness. Erase color setting.	CapsLock+ LeftShift	REC over, finish re
	Activate color palette to display various colors on each key, press on the desired color, all the keys will automatically change to match.	Recording steps: 1 Press Fn+Alt+CapLock 3 second G to set CM1 and press B to set CI 2 CapLock will display current LED Color can be adjusted by CapLoc- k+Z/X/C/V. After setting color, hittin	



By VirtuaLeech

cheatography.com/virtualeech/

## des

n+Alt+G	CM1 cycle: First step: Turn on user's customized zone and color. Second step: Turn on user's customized zone and color in breathe mode. Third step: Turn off CM1.
n+Alt+B	CM2 cycle: See CM1 cycle
n+Alt+ CapsLock REC)	Press for 3 seconds until the G (CM1) and B (CM2) keys light up, choose the layer for setting, press it again and start recording.
CapsLock+Z	Adjust color red (R)
apsLock+X	Adjust color green (G)
apsLock+C	Adjust color blue (B),
apsLock+V	Erase all LED light
CapsLock+ Spacebar	Color palette
CapsLock+ eftShift	REC over, finish recording

ds, press CM2. D color. X/X/C/V. After setting color, hitting any key on the keyboard will set that key to the selected color. 3 Repeating the above steps 4 Press CapLock+LeftShift to finish

recording.

Not published yet. Last updated 5th May, 2023. Page 1 of 1.

## Mouse mode Fn+W Mouse up Fn+A Mouse left Fn+S Mouse down Fn+D Mouse right Fn+Q Left moude button Fn+E Right mouse button Fn+R Scroll up Fn+F Scroll down

Mechanical shaft debounce time			
Fn+Alt+Y	5ms		
Fn+Alt+U	10ms (default)		
Fn+Alt+I	15ms		
Fn+Alt+O	25ms		

• Hold the combine keys for 3 sec, the keyboard will flash 3 times to indicate the debounce time has been switched successfully.

• The method is to adjust the debounce time of the metal shrapnel in the mechanical shaft during the pressing process. The shorter the time, the sooner it can be triggered, but if the time is too short may cause misjudgement.

Sponsored by Readable.com Measure your website readability! https://readable.com